

# Garageflex Assembly Instructions

Product: PowerTrack



## Package Contents:

- 1 x Piece of PowerTrack
- 6 x Screws

## Tools Required:

- Safety glasses
- Drill with 1/8" bit
- Phillips Screwdriver
- Stud finder and small drill bit / finishing nail
- Tape Measure
- Marker / Pencil



Unit 11 Westfield Farm  
Medmenham  
Buckinghamshire  
SL7 2TA

01491 579975 | [info@garageflex.co.uk](mailto:info@garageflex.co.uk)  
[www.garageflex.co.uk](http://www.garageflex.co.uk)

Step 1: Check the parts received

Step 2: Locate and mark the ceiling joist locations

Step 3: Cut the PowerTrack to the desired length if necessary using a JigSaw, Mitre Saw or Hacksaw

Step 4: Drill 1/8" holes at the determined joist locations, use the line inside the PowerTrack to centre the holes

Step 5: Screw into the ceiling joists. Use screws if mounting directly onto an exposed joist or through a single thickness of drywall.

Notes:

1. Try to mount the channel perpendicular to the ceiling joists as this spreads the load
2. Screw into the ceiling at every joist location, preferably every 406mm
3. Always screw the ends of the PowerTrack into a joist, don't leave the end hanging

If you have any questions or need some advice regarding your installation, please do get in touch and we will do our best to help.

You can contact us on:

01491 579975 | [info@garageflex.co.uk](mailto:info@garageflex.co.uk)  
[www.garageflex.co.uk](http://www.garageflex.co.uk)



Unit 11 Westfield Farm  
Medmenham  
Buckinghamshire  
SL7 2TA

01491 579975 | [info@garageflex.co.uk](mailto:info@garageflex.co.uk)  
[www.garageflex.co.uk](http://www.garageflex.co.uk)